

Fact Sheet

Refix/Repair Skirting

Tools

- Silicone gun
- Silicone
- Decorators caulk
- Dust pan and brush

Steps

1. Clean off debris on piece of skirting that needs to be refixed and the wall
2. Apply adhesive to the back side of the skirting
3. Push the skirting back into place and apply even pressure the whole way along – leave this to stand for 10 minutes
4. Apply a thin bead of decorators caulk to the joins and along the top to seal

5. If this is located within a bathroom use the adhesive to seal to the floor to make this water tight
6. Paint as required

We hope this information was helpful. If you are still experiencing problems with refixing or repairing your skirting, then please contact your repairs service.

You can also find a video to accompany this fact sheet at: www.mearsgroup.co.uk

These videos and accompanying guidance notes are intended as a guide only and it is your responsibility to ensure you do not put your safety or the safety of others at risk. If you are in any doubt as to whether you can carry out a task safely then you should contact a professional for assistance. Mears Group Plc and its subsidiaries will not be liable for any injury, loss or damage caused, of any nature, as a result of the use of these guides.